

INSTALLATION INSTRUCTIONS

Note: This mini instruction sheet is a summary of the detailed instruction sheet provided with each part.

INSTALLATION INSTRUCTIONS
BOLT-ON STEEL ROLL PAN
82-93 CHEVY/GMC S-10/S-15
PART# 1012888

For best results, please read all instructions thoroughly prior to attempting installation of your SIR MICHAEL'S weld-on steel roll pan. SIR MICHAEL'S recommends the use of approved hand, eye and ear safety equipment while performing this installation. If you have any questions concerning the installation of your SIR MICHAEL'S steel roll pan, please contact our customer service department at (714) 379-6800, Monday through Friday between the hours of 8:00 a.m. and 4:00 p.m. Pacific Standard Time (PST).

NOTE: Any part that is modified and/or painted are non returnable.

Remove the tailgate and rear bumper from truck.

Test fit roll pan to the body by sliding it up from the bottom. Using the #8 screws provided, bolt the roll pan on by inserting a screw through the end cap and into the side of the body.

Reinstall the tailgate and check for clearance, making sure the tailgate opens and shuts without hitting the roll pan. There is a support brace the bolts to the bottom of the roll pan and up to the bottom of the bed to keep the roll pan from vibrating.

After test fitting, remove tailgate and roll pan from vehicle to be prepped for paint. A lite coat of body filler is used to fill seams around the license plate and at the end of the roll pan. For good paint adhesion, sand down the roll pan completely before applying any primer or paint.

After roll pan has been color matched, install the license plate lite using the two #8 screws (DO NOT OVERTIGHTEN SCREWS). Snap in the plastic nuts into the square holes in the license plate box. Install your license plate with the two phillips head screws provided.

To wire up the license plate lite, connect one wire to the parking lite wire from the taillites and the other wire must be grounded to the frame.