

INSTALLATION INSTRUCTIONS

BOLT-ON TOW HITCH
00-XX CHEVY/GMC TAHOE & YUKON
PART# 1376147

For best results, please read all instructions thoroughly prior to attempting installation of your SIR MICHAEL'S products. SIR MICHAEL'S recommends the use of approved hand, eye and ear safety equipment while performing this installation. If you have any questions concerning the installation of your SIR MICHAEL'S steel roll pan, please contact our customer service department at (714) 379-6800, Monday through Friday between the hours of 8:00 a.m. and 4:00 p.m. Pacific Standard Time (PST).

NOTE: Any part that is modified and/or painted is non returnable.

1. All Sir Michaels tow hitches are designed to fit behind Sir Michaels steel roll pans.
2. This hitch will bolt to the two factory holes on each side of the frame.
3. Install hitch from the bottom up to the frame. Hitch will bolt on the bottom side of the frame.

Once all bolts are installed, tighten them down to factory specs. Hitch can now be accessed behind the license plate with a license plate flip, sold separately.

4. Sir Michaels does not supply a hitch wire plug and tow receiver due to the many different connections and drops. Most trailer and auto parts stores will carry those items.

Note: This hitch is not designed for use with lifted trucks or with use of drop receivers larger than a four inch drop. Use of larger drop receiver will void warranty.

Note: This hitch fits Tahoe/Yukon ONLY. The Suburban/Yukon XL rear mounted gas tank interferes with hitch mounting.